

EQUINOX

Event Booth

User Manual



Order codes:
EQLED049 - White
EQLED049A - Black

WARNING

FOR YOUR OWN SAFETY, PLEASE READ THIS USER MANUAL CAREFULLY BEFORE YOUR INITIAL START-UP!



- Site the booth on a level, stable surface
- Booth must be unfolded and setup as per diagram overleaf.
- Incorrect setup may lead to additional stress on the frame and components.
- Take care to keep fingers, body parts and loose clothing away from moving parts
- Main shelf loading: 25kg max. (evenly distributed), top shelf loading: 10kg
- Do not stand or sit on the shelf

Event Booth

A compact and portable foldable DJ stand supplied with steel shelf, white or black panels, shelves and a carry bags. The Equinox Event booth offers a fresh approach to DJ booths where the mesh upper facade provides some privacy to hide cables and connections without totally blocking the DJ from view.

Specifications	
Dimensions (H x W x D):	940 x 990 x 110mm (folded) 1075 x 1150 x 520mm (set-up) 910 x 990 x 490mm (internal)
Shelf height	945mm
TV bracket max. load	supports TVs up to 56"
Shelf max. load	25kg (shelf); 10kg (top shelf)
Frame weight	23.6kg
Shelf weight	4.6kg
Weight	34kg (system, excluding TV bracket)
TV bracket weight	3.71kg
Order codes	EQLED049 - White EQLED049A - Black



Includes sturdy shelf to support a variety of equipment




Carry Bags Included





TV bracket Included

To set up the Event Booth correctly, please follow the 8 steps below.





To set up the Event Booth correctly, please follow the 8 steps below.




Video instructions: [EQUINOX EVENT BOOTH](#)

To install the Event Booth TV bracket, please follow the 8 steps below.




To install the Event Booth TV bracket, please follow the 8 steps below.


Step 3




Step 4




Step 5



Step 6




Step 7



To install the Event Booth TV bracket, please follow the 8 steps below.

Step 8

Align with the slot position on the fixed frame



To detach the TV pull down on the fabric toggles and tilt the TV forwards before lifting off the bracket.