

www.cleveracoustics.co.uk



PM 200 DYNAMIC PAGING MICROPHONE WITH CHIME

Order code: CRMIC02

WARNING

FOR YOUR OWN SAFETY, PLEASE READ THIS USER MANUAL CAREFULLY BEFORE YOUR INITIAL START-UP!



SAFETY INSTRUCTIONS

Every person involved with the installation, operation & maintenance of this equipment should:

- Be competent
 - Follow the instructions of this manual

Before your initial start-up, please make sure that there is no damage caused during transportation. Should there be any, consult your dealer and do not use the equipment.

To maintain the equipment in good working condition and to ensure safe operation, it is necessary for the user to follow the safety instructions and warning notes written in this manual.

Please note that damages caused by user modifications to this equipment are not subject to warranty.

IMPORTANT:

The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorised modification to the equipment.

- Never remove warning or informative labels from the equipment.
- Do not open the equipment and do not modify the equipment.
- Do not switch the equipment on and off in short intervals, as this will reduce the system's life.
- Only use the equipment indoors.
- Do not expose to flammable sources, liquids or gases.
- Always disconnect the power from the mains when equipment is not in use or before cleaning! Only handle the power-cable by the plug. Never pull out the plug by pulling the power-cable.
- Make sure that the available voltage is DC 9V.
- Make sure that the power-cable is never crimped or damaged. Check the equipment and the power-cable periodically.
- If the equipment is dropped or damaged, disconnect the mains power supply immediately.

Have a qualified engineer inspect the equipment before operating again.

- If the equipment has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation might damage the equipment. Leave the equipment switched off until it has reached room temperature.
- If your product fails to function correctly, discontinue use immediately. Pack the unit securely (preferably in the original packing material), and return it to your Prolight dealer for service.
- Only use fuses of same type and rating.
- Repairs, servicing and power connection must only be carried out by a qualified technician. THIS UNIT CONTAINS NO USER SERVICEABLE PARTS.
- WARRANTY; One year from date of purchase.
- If this equipment is operated in any other way, than those described in this manual, the product may suffer damage and the warranty becomes void.
- Incorrect operation may lead to danger e.g.: short-circuit, burns, electric shock etc.
- Do not endanger your own safety and the safety of others! Incorrect installation or use can cause serious damage to people and property.

The PM 200 Paging microphone is designed to be used with the MA Mixer Amplifier Series.

Features

- Remote paging microphone with built-in chime
- Dynamic microphone capsule
- Cardioid polar pattern
- Push to talk button
- Connection: 3-pin XLR
- Supplied with 3-pin XLR to 6.35mm mono jack cable
- Powered either by 9V PP3 battery or optional
- 9V DC input (PSU not supplied)

Specifications	PM 200
Sensitivity:	-63dB
Frequency response:	50Hz-12kHz
Polar pattern:	Cardioid
Output impedance:	600Ω
Power supply:	9V DC
Dimensions (H x W x D):	125 x 150 x 455mm
Weight:	1.3kg
Order code:	CRMIC02

2		
J	 	

Overview:



Identification:


- 1. PM 200 microphone Connect the microphone to the PM 200 base stand uing the 3-pin XLR socket.
- 2. XLR mic input Use this socket to connect to the microphone.
- 3. Talk LED When the talk button has been pressed the LED will light up.
- 4. Talk button Use this button activate the talk function
- 5. 3-pin XLR output socket Use this socket to connet to your mixer amplifier.
- 6. DC 9V input Use the this socket to connect to a 9V DC adaptor (not supplied).
- 7. Optional 9V Alaline Battery power supply Use this to power the mic via a 9V battery.



5

Problem Chart

PROBLEM	CAUSE	REMEDY
lo Power The power supply is not connected		Check the power supply and any extension cables.
	Flat battery	Replace with new 9V DC PP3 Alkaline or remove battery and operate using power supply.
No Sound	The power supply of the respective product is not connected properly or not at all.	Check the power supply and if the plugs are properly connected with the sockets.
	The connection socket or the plug is dirty.	Clean the socket and/or the plug.
Noise	The input signal is too strong	Reduce the input signal via the gain control.
Distorted Sound	Input is too strong	Ensure the user is not shouting into the microphone or positioning the microphone too close to the users mouth.



Cleaning and Maintenance

We recommend a frequent cleaning of the product. Please use a soft lint free and moistened cloth. Never use alcohol or solvents.

There are no serviceable parts inside the product except for the fuse. Maintenance and service operations are only to be carried out by authorised dealers.

Should you need any spare parts, please use genuine parts.

Should you have any further questions, please contact your dealer.

English



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with seperate collection systems)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please seperate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.



www.cleveracoustics.co.uk