

User manual


CST-20 CST-50



1. Attention:

- Do not install the module near high inflammable liquids or materials.
- Do not allow anything to rest on the module.
- Do not use the module near high humidity or water or expose to the rain.
- Do not install the module near the naked flames.
- Do not install the module in dirty, dusty or badly ventilated location.


2. Device connection:



Pin	Color	Function
1	Red	Red
2	Green	Green
3	Blue	Blue
4	White	24V +

3. Typical installation:

Please use an adapter cable to connect both terminal side of CST-20 CST-50, please make sure the signal input and signal output of CST-20 CST-50 was link Color Commander correctly.



CAUTIONS: Ensure the main power supply is off before installation

4. Technical specifications:

- Power consumption: 3.4W (CST-50)
1.7W (CST-20)
- Power supply: DC 24V

5. Maintenance

- Keep the module dry.
- Operate only in places where the sufficient air ow to cool the module is present.
- Periodically clean the front transparent cover. Use a moist, lint-free cloth. Never use alcohol or solvents!