

Spectra Flood Q15HEX PRO Exterior Fixture

User Manual



Order code: LEDJ587A



WARNING

FOR YOUR OWN SAFETY, PLEASE READ THIS USER MANUAL CAREFULLY BEFORE YOUR INITIAL START-UP!

- Before your initial start-up, please make sure that there is no damage caused during transportation.
- Should there be any damage, consult your dealer and do not use the equipment.
- To maintain the equipment in good working condition and to ensure safe operation, it is necessary for the user to follow the safety instructions and warning notes written in this manual.
- Please note that damages caused by user modifications to this equipment are not subject to warranty.



CAUTION!
TAKE CARE USING
THIS EQUIPMENT!
HIGH VOLTAGE-RISK
OF ELECTRIC SHOCK!!

IMPORTANT:

The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorised modification to the equipment.

- Never let the power cable come into contact with other cables. Handle the power cable and all mains voltage connections with particular caution!
- · Never remove warning or informative labels from the unit.
- Do not open the equipment and do not modify the unit.
- Do not connect this equipment to a dimmer pack.
- Do not switch the equipment on and off in short intervals, as this will reduce the system's life.
- Only use the equipment indoors.
- Do not expose to flammable sources, liquids or gases.
- Always disconnect the power from the mains when equipment is not in use or before cleaning! Only handle the power-cable by the plug. Never pull out the plug by pulling the power-cable.
- Make sure that the available mains supply voltage is between 100~240V AC, 50/60Hz.
- Make sure that the power cable is never crimped or damaged. Check the equipment and the power cable periodically.
- Never touch the fixture during operation as it may be hot.
- If the equipment is dropped or damaged, disconnect the mains power supply immediately and have a qualified engineer inspect the equipment before operating again.

- If your product fails to function correctly, stop use immediately. Pack the unit securely (preferably in the original packing material), and return it to your Pro Light dealer for service.
- · Only use fuses of same type and rating.
- Repairs, servicing and power connection must only be carried out by a qualified technician. THIS UNIT CONTAINS NO USER SERVICEABLE PARTS.
- Warning! Risk Group 2 LED product according to EN 62471. Keep a distance of at least 11feet (3.3m) to avoid direct eye and skin exposure. Do not operate the fixture if the external cover protective lens is damaged or missing. Avoid direct viewing of the UV light and refrain from using optical instruments or any device that may concentrate the light/radiation output. We advise users to take necessary precautions to minimise direct exposure to UV radiation and individuals suffering from a range of eye conditions, sunlight exposure disorders, or individuals using photosensitive medication, may receive discomfort if exposed to the ultraviolet (UV) light emitted from this fixture.
- Warning! Risk Group 2 LED product according to EN 62471. Do not view the light output with optical instruments or any device that may concentrate the beam.
- · WARRANTY: One year from date of purchase.

OPERATING DETERMINATIONS

If this equipment is operated in any other way, than those described in this manual, the product may suffer damage and the warranty becomes void. Incorrect operation may lead to danger e.g. short-circuit, burns and electric shocks etc.

Do not endanger your own safety and the safety of others!

Incorrect installation or use can cause serious damage to people and/or property.

Please note: These fixtures are intended for stage lighting and entertainment applications only, and are not intended for extended periods of use, including but not limited to house-light, industrial or architectural applications and should only be operated with short duty cycles.



Product overview & technical specifications

Spectra Flood Q15HEX PRO Exterior Fixture

The LEDJ IP65 rated Spectra Q HEX series bathes architectural details in constantly changing colours from its high output LEDs. The wide beam angle smoothly washes facades and features in deep rich colours or warm pastel tones. The rugged aluminium exterior ensures years of use in most weather conditions while the integral mounting brackets complete the fixtures sleek, modern appearance. The OLED display with 4 button menu facilitates control over colour mixing, colour fades, chases and DMX, whilst the silent running, convection cooled enclosure features PowerTwist TR1 and 5-Pin DMX inputs and outputs to allow for a problem-free, rental-ready connection.



• Beam angle: 40°

• 1,405 Lux @ 2m (full on)

· Refresh rate: 12kHz

• DMX channels: 6/8 or 12 selectable

• RDM (Remote Device Management)

 Static colour, colour change, colour fade, auto and master/slave modes

• 0 - 100% dimming

 4 dimming curves: Linear, square law, inverse square law and S-curve

· Variable strobe

Quick release omega clamp included

· 4 button menu with OLED display

• PowerTwist TR1 input/output

• IP rated 5-Pin XLR input/output


· Convection cooled


· Optional IR Remote (LEDJ90J)




Specifications	Spectra Flood Q15HEX PRO Exterior Fixture			
Power consumption	84W			
Power supply	100~240V, 50/60Hz			
IP rating	IP65			
Dimensions	207 x 330 x 110mm			
Weight	5.2kg			
Order code	LEDJ587A			
40° - Lux FULL ON 5620 R 1692 G 2756 B 608 W 3740	1405 624 351 224 423 188 105 67.6 689 306 172 110 152 67.5 38 24.3 935 415 233 149			











01 - Bracket

02 - OLED display

03 - Function buttons

04 - PowerTwist TR1 input

05 - PowerTwist TR1 output

06 - 5-Pin DMX input


07 - 5-Pin DMX output

In the box: 1 x fixture, 1 x omega clamp & 1 x power cable



Installation:

- 1. Fasten each clamp to the omega clamps with a bolt and lock nut through the hole in the omega clamp.
- 2. Align and insert the omega clamp quick-lock fasteners with the respective holes on the bottom of the unit.
- 3. Tighten both locking fasteners clockwise on each omega clamp ensuring they're fully secure.
- 4. Mount the fixture onto your truss system via the clamps and tighten to ensure secure.
- 5. Pull the safety cable through the safety cable holes located on the metal base plate on the underside of the fixture and around the truss.





<u>IMPORTANT! PLEASE NOTE:</u> The OLED display for this fixture has a menu locking function where after 20 seconds of inactivity it will lock. To unlock the menu hold the "MODE" and "SET" buttons for 3 seconds.

Main Menu	Sub Menu	Options/Values	Description	
	1) Address:	001-512	DMX Address Setting	
4 514		06 (6 channel mode)	DMX Channel Setting	
1:DMX	2) Channels:	08 (8 channel mode)		
		12 (12 channel mode)		
	1) Red	000-255		
	2) Green	000-255]	
0.0:	3) Blue	000-255	Manual Binaria (Mada	
2:Dimmer	4) White	000-255	Manual Dimming Mode	
	5) Amber	000-255		
	6) UV	000-255		
3:Auto			Auto Mode	
	1) Mode:	01-16		
A-Dua dua us	2) Color: (Mode 1)	00-33	Built in Burdana	
4:Program	2) Speed: (Mode 2-14)	001-100	Built-in Programs	
	3) Strobe	00-99		
5:Slave			Slave Mode Setting	
		1) Linear		
		2) Square Law		
	1) Curves Select	3) Inv Square Law	Dimming Curves Setting	
		4) S-Type		
	O) Dinaman Craad	Fast	Diagramia & Oversia & Control & Cattling	
	2) Dimmer Speed	Smooth	Dimming Curves Speed Setting	
		Off		
0.0 -44'	2) D 5-11	Hold	7	
6:Settings	3) Dmx Fail	Dimmer	DMX Signal Failure Setting	
		Program		
	4) D C	On	DMV 0	
	4) Dmx Sync	Off	DMX Synchronisation Setting	
	E) I and	Yes	Disabel and Catting	
	5) Lock	No	Display Lock Setting	
	C) Factors	Yes	Footon Book	
	6) Factory	No	Factory Reset	
	Versions:		Software Version	
7.lmfa	Temperature:		Fixture Temperature	
7:Information	Work Time:		Fixtures Run Time	
	UID:		Fixtures UID	



DMX channel modes:

Channel				Function		
06	08	12	Value	Funct	ion	
-	1	1	000-255	Master dimmer (0-100%)		
	- 2	2	000-010	No function	Linear Strobe	
-		2	011-255	Strobe (slow-fast)	Linear Strobe	
		2	000-010	No function	Dandons Ctrobo	
-	-	3	011-255	Strobe (slow-fast)	Random Strobe	
			000-007	No function		
			008-013	Colour 01		
			014-020	Colour 02		
			021-027	Colour 03		
			028-034	Colour 04		
			035-041	Colour 05		
			042-048	Colour 06		
			049-055	Colour 07		
			056-062	Colour 08		
			063-069	Colour 09		
			070-076	Colour 10		
			077-083	Colour 11		
		4	084-090	Colour 12		
			091-097	Colour 13		
			098-104	Colour 14		
			105-111	Colour 15		
			112-118	Colour 16		
-	-		119-125	Colour 17		
			126-132	Colour 18		
			133-139	Colour 19		
			140-146	Colour 20		
			147-153	Colour 21		
			154-160	Colour 22		
			161-167	Colour 23		
			168-174	Colour 24		
			175-181	Colour 25		
			182-188	Colour 26		
			189-195	Colour 27		
			196-202	Colour 28		
			203-209	Colour 29		
			210-216	Colour 30		
			217-223	Colour 31		
			224-230	Colour 32		
			231-255	Colour 33		





DMX channel modes (cont.):

Channel					
06	08	12	Value	Function	
			000-015	No function	
			016-031	Colour Change 1	
			032-047	Colour Change 2	
			048-063	Colour Change 3	
			064-079	Colour Change 4	
			080-095	Colour Change 5	
			096-111	Colour Change 6	
		5	112-127	Colour Change 7	Duilt in myodyomo
		5	128-143	Colour Change 8	Built-in programs
			144-159	Colour Fade 1	
			160-175	Colour Fade 2	
			176-191	Colour Fade 3	
			192-207	Colour Fade 4	
			208-223	Colour Fade 5	
			224-239	Colour Fade 6	
			240-255	Colour Fade 7	
		6	000-255	Speed (slow-fast)	
1	3	7	000-255	Red dimmer (0-100%)	
2	4	8	000-255	Green dimmer (0-100%)	
3	5	9	000-255	Blue dimmer (0-100%)	
4	6	10	000-255	White dimmer (0-100%)	
5	7	11	000-255	Amber dimmer (0-100%)	
6	8	12	000-255	UV dimmer (0-100%)	



RDM (Remote Device Management):

The LEDJ Spectra Q HEX Series supports RDM communication protocol. RDM supports 2-way traffic in the standard DMX-512 protocol. RDM can control devices, configurations, detect fixtures and allows the changing of DMX address, DMX mode etc. Each RDM compatible fixture can be identified by the built-in unique UID code. To display the UID go to **7:Information** in the menu and the UID will be displayed.

Parameter ID	Discovery command	Set command	Get command
DISC_UNIQUE_BRANCH	*		
DISC_MUTE	*		
DISC_UN_MUTE	*		
DEVICE_INFO			*
SOFTWARE_VERSION_LABEL			*
DMX_START_ADDRESS		*	*
IDENTIFY_DEVICE		*	*
SUPPORTED_PARAMETERS			*
SENSOR_DEFINITION			*
SENSOR_VALUE			*
DMX_PERSONALITY		*	*
DMX_PERSONALITY_DESCRIPTION			*
RESET_DEVICE		*	
FACTORY_DEFAULTS		*	



Setting the DMX address:

The DMX mode enables the use of a universal DMX controller. Each fixture requires a "start address" from 1-512. A fixture requiring one or more channels for control begins to read the data on the channel indicated by the start address. For example, a fixture that occupies or uses 7 channels of DMX and was addressed to start on DMX channel 100, would read data from channels: 100, 101, 102, 103, 104, 105 and 106. Choose a start address so that the channels used do not overlap. E.g. the next unit in the chain starts at 107.

DMX 512:

DMX (Digital Multiplex) is a universal protocol used as a form of communication between intelligent fixtures and controllers. A DMX controller sends DMX data instructions form the controller to the fixture. DMX data is sent as serial data that travels from fixture to fixture via the DATA "IN" and DATA "OUT" XLR terminals located on all DMX fixtures (most controllers only have a data "out" terminal).

DMX linking:

DMX is a language allowing all makes and models of different manufactures to be linked together and operate from a single controller, as long as all fixtures and the controller are DMX compliant. To ensure proper DMX data transmission, when using several DMX fixtures try to use the shortest cable path possible. The order in which fixtures are connected in a DMX line does not influence the DMX addressing. For example; a fixture assigned to a DMX address of 1 may be placed anywhere in a DMX line, at the beginning, at the end, or anywhere in the middle. When a fixture is assigned a DMX address of 1, the DMX controller knows to send DATA assigned to address 1 to that unit, no matter where it is located in the DMX chain.

DATA cable (DMX cable) requirements (for DMX operation):

This fixture can be controlled via DMX-512 protocol. The DMX address is set on the back of the unit. Your unit requires a standard 5-pin XLR connector for data input/output, see images below.



Further DMX cables can be purchased from all good sound and lighting suppliers or Prolight Concepts dealers.


Please quote: 5-Pin: CABL185 - 2m CABL187 - 5m CABL188 - 10m

Also remember that DMX cable must be daisy chained and cannot be split.



Notice:

Be sure to follow the diagrams below when making your own cables. Do not connect the cables shield conductor to the ground lug or allow the shield conductor to come in contact with the XLRs outer casing. Grounding the shield could cause a short circuit and erratic behaviour.



XLR MALE SO	CKET	XLR F	EMALE SOC	KET
1 ground	2 cold	2 cold		1 ground


XLR Pin Configuration	
Pin 1 = Ground	
Pin 2 = Negative	
Pin 3 = Postive	

Special note:

Line termination:

When longer runs of cable are used, you may need to use a terminator on the last unit to avoid erratic behaviour.

Using a cable terminator will decrease the possibilities of erratic behaviour.




Termination reduces signal transmission problems and interferance. it is always advisable to connect a DMX terminal, (resistance 120 Ohm 1/4 W) between pin 2 (DMX-) and pin 3 (DMX+) of the last fixture.

(3-pin - Order ref: CABL90, 5-pin - Order ref: CABL89)

5-pin XLR DMX connectors:

Some manufactures use 5-pin XLR connectors for data transmission in place of 3-pin. 5-pin XLR fixtures may be implemented in a 3-pin XLR DMX line. When inserting standard 5-pin XLR connectors in to a 3-pin line a cable adaptor must be used. The diagram below details the correct cable conversion.






Power linking:

This fixture provides power linking via the power output on the rear allowing multiple units to be connected together. The maximum number of fixtures that can be connected is 18 fixtures @ 240V or 9 fixtures @ 120V (including the first fixture). After the maximum number of fixtures are connected a new power run will need to be started.

Please note: Caution should be used when power linking other fixtures to the Spectra Flood Q15HEX PRO Exterior Fixture as the power consumption of other fixtures will vary. Fixtures fitted with lamps often require 2/3 times more current on startup, these may require their own power source.







Correct Disposal of this Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

